


# MUTOH

## MAINTENANCE MANUAL (Notes on installation)

### XPJ-1462UF



XPJ1462UFE-M-EX-00

CONFIDENTIAL

## TOC

TOC.....	2
<b>1. Introduction .....</b>	<b>3</b>
<b>2. Notes on installation .....</b>	<b>4</b>
<b>3. Y-rail height adjustment .....</b>	<b>5</b>
3.1. Y-rail height adjustment(check) .....	5
3.2. Y-rail height adjustment(adjustment).....	6
<b>4. UV-LED height adjustment .....</b>	<b>8</b>
4.1. UV-LED height adjustment(check) .....	8
4.2. UV-LED height adjustment(adustment).....	10
<b>5. Y-rail horizontal adjustment.....</b>	<b>12</b>
5.1. Install jig .....	12
5.2. Y-rail horizontal adjustment(check).....	13
5.3. Y-rail horizontal adjustment(adjustment) .....	15
<b>6. Laser sensor adjutment .....</b>	<b>17</b>
6.1. Laser sensor adjustment(check) .....	20
6.2. Laser sensor adjustment(adjustment).....	23
<b>7. Check gantry operation .....</b>	<b>28</b>
7.1. Check gantry operation(check).....	29
7.2. Check gantry operation(adjustment) .....	30
<b>Appendix.1. Self-diagnosis .....</b>	<b>32</b>
Appendix.1.1. PG height adjustment.....	32
Appendix.1.2. Laser sensor adjustment .....	33
Appendix.1.3. UV-LED mounting position adjustment .....	33
Appendix.1.4. Gantry move .....	34

## 1. Introduction

**NOTE**

- Applicable model : XPJ-1462UF
- Applicable manual : XPJ1462UFE-M-01 or later
- Applicable Firmware : Ver.1.01 or later.
- Date of enactment :September 15, 2023.


**TIP**

index=> [TOC](#)

## 2. Notes on installation

**CAUTION**

- Do not touch moving parts (gantry) when transporting or moving the printer.  
There is a risk of misalignment.

**NOTE**


- If gantry is touched, check for accuracy and operation problems.  
\*When installing XPJ-1462UF, it is recommended to check mechanical accuracy.
  - Confirmation procedure 1 : Y-rail height inspection  
Using jig, verify if distance between print head and table is within specification.  
=>**3. Y-rail height adjustment**
  - Confirmation procedure 2 : UV-LED height inspection  
Using jig, verify if distance between UV-LED and table is within specification.  
=>**4. UV-LED height adjustment**
  - Confirmation procedure 3 : Y-rail levelness inspection  
Using jig, verify that height on left and right sides of Y-rail is level.  
=>**5. Y-rail horizontal adjustment**
  - Confirmation procedure 4 : Media height detector inspection  
Using jig and tools, verify position of media height detector.  
=>**6. Laser sensor adjustment**
  - Confirmation procedure 5 : Gantry movement inspection  
Using printer control panel, move gantry to see if it moves properly.  
=>**7. Check gantry operation**

**TIP**

index=> [TOC](#)

## 3. Y-rail height adjustment

A : Y-rail




## ● Tools, Jigs, and Maintenance Part(s)

Part(s) No.	Name	Reference
DG-46922	PG Adjustment Jig(1.3-1.4)	

**NOTE**

DG-46922  
PG Adjustment Jig (1.3-1.4)  
Ⓐ Adjustment jig

**TIP**

index=> [TOC](#)

## 3.1. Y-rail height adjustment(check)

## ● Procedure

- 1 Select check menu.  
- [Check1:Adj.Mecha] -> [Mecha5:Adj. UV Lamp] -> [Start Adj.->Enter]
- 2 Move gantry.  
- [Start Adj.->Enter] -> [Wait for a while] -> [Adjust End->Enter]
- 3 Place jig.
- 4 Check head height.(print head 1)
- 5 Remove jig.
- 6 Exit check menu.  
- [Adjust End->Enter] -> [Mecha5:Adj. UV Lamp]

## ● Procedure(details)

- 1 Select check menu.  
- Starts self-diagnosis function mode.  
- Select check menu.  
- [Check1:Adj.Mecha]  
->[Mecha5:Adj. UV Lamp]  
->[Start Adj.->Enter]
- 2 Move gantry.  
- [Start Adj.->Enter]  
- Press "Enter" key.  
->[Wait for a while]  
- Gantry automatically moves to adjustment position.  
- Carriage automatically caps out.  
- [Adjust End->Enter]

- 3 Place jig.  
- Place jig on table.


A : Table

B : Jig

C : Screw

**NOTE**

- Place jig at third screw point from right side.
- Place jig in same point each time.



- 4 Check head height.(print head 1)  
- Check if head goes through 1.3mm, and stop at 1.4mm step of jig.

- If value is out of specified value, perform Y-rail height adjustment.

=>3.2. Y-rail height adjustment(adjustment)

A : Print head 1


B : Jig

C : Table

D : Carriage

**NOTE**

- Move carriage slowly.



- 5 Remove jig.

- 6 Exit check menu.  
- [Adjust End->Enter]  
- Press "Enter" key.  
- Carriage automatically caps in.  
- [Mecha5:Adj. UV Lamp]

**TIP**

index=> [TOC](#)

### 3.2. Y-rail height adjustment(adjustment)

● Procedure

- 1 Select adjustment menu.  
- [Check1:Adj.Mecha] -> [Mecha1:Adj.PG] -> [PG1:Adjust Height] -> [Start Adj.->Enter]
- 2 Move gantry.  
- [Start Adj.->Enter] -> [Wait for a while] -> [Adj. Height:\*.\*\*mm]
- 3 Adjust Y-rail height.  
- [Adj. Height:\*.\*\*mm]
- 4 Exit adjustment menu.  
- [Adj. Height:\*.\*\*mm] -> [Wait for a while] -> [PG OK? No/Yes]-> [PG1:Adjust Height]
- 5 Check head height.(print head 1)

● Procedure(details)

- 1 Select adjustment menu.  
- Starts self-diagnosis function mode.  
- Select adjustment menu.  
- [Check1:Adj.Mecha]  
->[Mecha1:Adj.PG]  
->[PG1:Adjust Height]  
->[Start Adj.->Enter]

- 2 Move gantry.  
- [Start Adj.->Enter]  
- Press "Enter" key.  
->[Wait for a while]  
- Gantry automatically moves to adjustment position.  
- [Adj. Height:\*.\*\*mm]

- 3 Adjust Y-rail height.
- If value is outside specified value, enter value in [Adj. Height:\*.\*\*mm].
  - Press "Enter" key.

**NOTE**

- If 1.3mm step does not go through: add +0.05 mm
- If 1.4mm step does not stop: add -0.05 mm


- 4 Exit adjustment menu.
- [Adj. Height:\*.\*\*mm]
  - >[Wait for a while]
  - Gantry automatically moves to origin position.
  - [PG OK? No/Yes]
  - Select "Yes".
  - [PG1:Adjust Height]

- 5 Check head height.(print head 1)  
=>**3.1. Y-rail height adjustment(check)**
- Check if head goes through 1.3mm, and stop at 1.4mm step of jig.
  - If value is out of specified value, perform Y-rail height adjustment.
  - >Repeat steps 1~5.

A : Print head 1  
B : Jig  
C : Table  
D : Carriage

**NOTE**


- Move carriage slowly.

**TIP**

index=> [TOC](#)

## 4. UV-LED height adjustment

A : UV-LED(left side)  
B : UV-LED(right side)




## ● Tools, Jigs, and Maintenance Part(s)

Part(s) No.	Name	Reference
DH-41689	UV Lamp Height Calibration Jig	
Generic item	Phillips screwdriver No.2	
Generic item	Ratchet screwdriver	- for adjustment

**NOTE**

DH-41689  
UV Lamp Height Calibration Jig  
Ⓐ Jig

**TIP**

index=> [TOC](#)

## 4.1. UV-LED height adjustment(check)

## ● Procedure

- 1 Select check menu.
  - [Check1:Adj.Mecha] -> [Mecha5:Adj. UV Lamp] -> [Start Adj.->Enter]
- 2 Move gantry.
  - [Start Adj.->Enter] -> [Wait for a while] -> [Adjust End->Enter]
- 3 Place jig.
- 4 Check UV-LED height.(left side)
- 5 Check UV-LED height.(right side)
- 6 Remove jig.
- 7 Exit check menu.
  - [Adjust End->Enter] -> [Mecha5:Adj. UV Lamp]

## ● Procedure(details)

- 1 Select check menu.
  - Starts self-diagnosis function mode.
  - Select check menu.
    - [Check1:Adj.Mecha]
    - >[Mecha5:Adj. UV Lamp]
    - >[Start Adj.->Enter]
- 2 Move gantry.
  - [Start Adj.->Enter]
  - Press "Enter" key.
  - >[Wait for a while]
  - Gantry automatically moves to adjustment position.
  - Carriage automatically caps out.
  - [Adjust End->Enter]

- 3 Place jig.  
- Place jig on table.


A : Table

B : Jig

C : Screw

**NOTE**

- Place jig at third screw point from right side.
- Place jig in same point each time.



- 4 Check UV-LED height.(left side)  
- Check if head goes through 1.8mm, and stop at 2mm step of jig.  
- If value is out of specified value, perform UV-LED height adjustment.

=>4.2. UV-LED height adjustment(adustment)

A : UV-LED(left side)

B : UV-LED base plate(left side)


C : Jig

D : Table

E : Carriage

**NOTE**

- Move carriage slowly.



- 5 Check UV-LED height.(right side)  
- Check if head goes through 1.8mm, and stop at 2mm step of jig.  
- If value is out of specified value, perform UV-LED height adjustment.  
=>4.2. UV-LED height adjustment(adustment)

A : UV-LED(right side)

B : UV-LED base plate(right side)


C : Jig

D : Table

E : Carriage

**NOTE**

- Move carriage slowly.



- 6 Remove jig.

- 7 Exit check menu.  
- [Adjust End->Enter]  
- Press "Enter" key.  
- Carriage automatically caps in.  
- [Mecha5:Adj. UV Lamp]

**TIP**

index=> [TOC](#)

## 4.2. UV-LED height adjustment(adustment)

**NOTE**

- Adjustment method is same for both right and left sides.  
(This procedure is height adjustment procedure for UV-LED (left side).)

**CAUTION**

- This procedure is for adjusting height of UV-LED with power on.  
Do not disconnect UV-LED cable.

## ● Procedure


- 1 Select check menu.
  - [Check1:Adj.Mecha] -> [Mecha5:Adj. UV Lamp] -> [Start Adj.->Enter]
- 2 Move gantry.
  - [Start Adj.->Enter] -> [Wait for a while] -> [Adjust End->Enter]
- 3 Remove CR cover.
  - Round head screw with split washer(polished)\_M3x6(black)(x4)
- 4 Remove Connector cover L.
  - Round head screw with split washer\_M3x6(x2)
- 5 Remove UV-LED Assy(left side).
  - Round head screw with split washer\_M3x6(x3)
- 6 Loosen screw(s).
  - Round head screw with split washer\_M3x8(x4)
- 7 Adjust UV-LED height.(front side)
- 8 Adjust UV-LED height.(rear side)
- 9 Tighten the screw(s).
  - Round head screw with split washer\_M3x8(x4)
- 10 Install UV-LED Assy(left side).
  - Round head screw with split washer\_M3x6(x3)
- 11 Check UV-LED height.
- 12 Reverse the above procedure to reinstall the parts.
- 13 Exit check menu.

## ● Procedure(details)

- 1 Select check menu.
  - Starts self-diagnosis function mode.
  - Select check menu.
    - [Check1:Adj.Mecha]
    - >[Mecha5:Adj. UV Lamp]
    - >[Start Adj.->Enter]
- 2 Move gantry.
  - [Start Adj.->Enter]
  - Press "Enter" key.
    - >[Wait for a while]
    - Gantry automatically moves to adjustment position.
    - Carriage automatically caps out.
  - [Adjust End->Enter]


- 3 Remove CR cover.
  1. Open clamp. (Right side)
  2. Open clamp. (left side)
  3. Remove screw(s).
    - Round head screw with split washer(polished)\_M3x6(black)(x3)
  4. Remove CR cover.

A : CR cover




- 4 Remove Connector cover L.
  1. Remove screw(s).
    - Round head screw with split washer\_M3x6(x2)
  2. Remove Connector cover L.

A : Connector cover L




- 5 Remove UV-LED Assy(left side).
- Remove UV-LED Assy.
    - Round head screw with split washer\_M3x6(x3)
  - Remove UV-LED Assy(left side).
  - Place UV-LED Assy (left side) on table.
- A : Round head screw with split washer\_M3x6(x3)  
 B : Lamp base  
 C : UV-LED Assy(left side)  
 D : UV-LED cable


**CAUTION**

- Do not disconnect UV-LED cable..


- 6 Loosen screw(s).
- A : Round head screw with split washer\_M3x8(x4)  
 B : UV-LED base plate(left side)




- 7 Adjust UV-LED height.(front side)
- Place jig under UV-LED base plate.
  - Turn adjustment screw so that UV-LED base plate touches jig (2 mm).
- A : Adjustment screw(Pan head small screw\_M3x25)(x1)  
 B : UV-LED base plate(left side)  
 C : Jig



- 8 Adjust UV-LED height.(rear side)
- Place jig under UV-LED base plate.
  - Turn adjustment screw so that UV-LED base plate touches jig (2 mm).
- A : Adjustment screw(Pan head small screw\_M3x25)(x1)  
 B : UV-LED base plate(left side)  
 C : Jig



- 9 Tighten the screw(s).
- A : Round head screw with split washer\_M3x8(x4)  
 B : UV-LED base plate(left side)



- 10 Install UV-LED Assy(left side).  
 => Refer to step.5.

- 11 Check UV-LED height.  
 => **4.1. UV-LED height adjustment(check)**

- 12 Reverse the above procedure to reinstall the parts.


- 13 Exit check menu.
- [Adjust End->Enter]
  - Press "Enter" key.
    - Carriage automatically caps in.
  - [Mecha5:Adj. UV Lamp]

**TIP**

index=> [TOC](#)

5. Y-rail horizontal adjustment

A : Y-rail




● Tools, Jigs, and Maintenance Part(s)

Part(s) No.	Name	Reference
DH-41896	Table Measurement Jig	

**NOTE**


DH-41896  
Table Measurement Jig  
Ⓐ Jig



**NOTE**

- Push down lift lever will raise contact point.

A : Lift lever  
B : Contact point



**TIP**

index=> [TOC](#)


5.1. Install jig

● Procedure



- 1 Lower bearing. (x2)
- 2 Install jig to Y-rail.
- 3 Raise bearing.(x2)

● Procedure(details)


- 1 Lower bearing. (x2)  
A : Bearing




- 2 Install jig to Y-rail.  
A : Y-rail  
B : Jig



- 3 Raise bearing.(x2)  
A : Bearing

**CAUTION**

- When gantry operates, move jig to counter origin side.  
A:Jig

**TIP**

index=> [TOC](#)

## 5.2. Y-rail horizontal adjustment(check)


## ● Procedure

- 1 Select adjustment menu.  
- [Check1:Adj.Mecha] -> [Mecha1:Adj.PG] -> [PG1:Adjust Height] -> [Start Adj.->Enter]
- 2 Move gantry.  
- [Start Adj.->Enter] -> [Wait for a while] -> [Adj. Height:\*.\*\*mm]
- 3 Install jig.
- 4 Move jig.(measuring point on origin side)
- 5 Set scale.(measuring point on origin side)
- 6 Move jig.(measuring point on counter origin side)
- 7 Check scale.(measuring point on counter origin side)
- 8 Move jig.(counter origin side)
- 9 Exit adjustment menu.  
- [Adj. Height:\*.\*\*mm] -> [Wait for a while] -> [PG OK? No/Yes] -> [PG1:Adjust Height]


## ● Procedure(details)

- |   |   |
|---|---|
| 1 | <p>Select adjustment menu.</p> <ul style="list-style-type: none"> <li>- Starts self-diagnosis function mode.</li> <li>- Select adjustment menu.<br/>- [Check1:Adj.Mecha]<br/>-&gt;[Mecha1:Adj.PG]<br/>-&gt;[PG1:Adjust Height]<br/>-&gt;[Start Adj.-&gt;Enter]</li> </ul> |
| 2 | <p>Move gantry.</p> <ul style="list-style-type: none"> <li>- [Start Adj.-&gt;Enter]</li> <li>- Press "Enter" key.<br/>-&gt;[Wait for a while]<br/>- Gantry automatically moves to adjustment position.</li> <li>- [Adj. Height:*.**mm]</li> </ul>                         |
| 3 | <p>Install jig.<br/>=&gt;<a href="#">5.1. Install jig</a></p>   |


- 4 Move jig.(measuring point on origin side)  
 A : Jig  
 B : Measuring point  
 C : Table



- 5 Set scale.(measuring point on origin side)  
 - Rotate scale to "0".  
 - Check short hand value.  
 A : Dial gauge



- 6 Move jig.(measuring point on counter origin side)  
 A : Jig  
 B : Measuring point  
 C : Table



- 7 Check scale.(measuring point on counter origin side)  
 - Check that scale is within specified value.  
 - If value is out of specified value, perform Y-rail horizontal adjustment.  
 =>5.3. Y-rail horizontal adjustment(adjustment)

A : Dial gauge

**NOTE**


- Specified value :  $\pm 0.05\text{mm}$



- 8 - Move jig.(counter origin side)  
 A : Jig

**CAUTION**

- When finishing adjustment menu, gantry moves automatically and jig is moved out of the way.
- If no adjustment is to be made, remove jig.



- 9 Exit adjustment menu.  
 - [Adj. Height:\*.\*\*mm]  
 ->[Wait for a while]  
 - Gantry automatically moves to origin position.  
 - [PG OK? No/Yes]  
 - Select "Yes".  
 - [PG1:Adjust Height]

**TIP**

index=> [TOC](#)

## 5.3. Y-rail horizontal adjustment(adjustment)


## ● Procedure

- 1 Perform steps 1~5 of "5.2. Y-rail horizontal adjustment(check)".
- 2 Move jig.(measuring point on counter origin side)
- 3 Check scale.(measuring point on counter origin side)
- 4 Adjust Y-rail horizontal.(measuring point on counter origin side)
  - [Adj. Tilt:\*.\*\*mm]
- 5 Repeat steps 3~4.(measuring point on counter origin side)
- 6 Move jig.(measuring point on origin side)
- 7 Check scale.(measuring point on origin side)
- 8 Adjust Y-rail horizontal.(measuring point on origin side)
  - [Adj. Height:\*.\*\*mm]
- 9 Repeat steps 7~8.(measuring point on origin side)
- 10 Repeat steps 2~9.
- 11 Remove jig.
- 12 Exit adjustment menu.
  - [Adj. Height:\*.\*\*mm] -> [Wait for a while] -> [PG OK? No/Yes] -> [PG1:Adjust Height]

## ● Procedure(details)

- 1 Perform steps 1~5 of "5.2. Y-rail horizontal adjustment(check)".
  - 1 Select adjustment menu.
    - [Check1:Adj.Mecha]
    - > [Mecha1:PAAdj.PG]
    - > [PG1:Adjust Height]
    - > [Start Adj.->Enter]
  - 2 Move gantry.
    - [Start Adj.->Enter]
    - > [Wait for a while]
    - > [Adj. Height:\*.\*\*mm]
  - 3 Install jig.
  - 4 Move jig.(measuring point on origin side)
  - 5 Set scale.(measuring point on origin side)

- 2 Move jig.(measuring point on counter origin side)
  - A : Jig
  - B : Measuring point
  - C : Table




- 3 Check scale.(measuring point on counter origin side)
- Check that scale is within specified value.
  - If value is out of specified value, perform Y-rail horizontal adjustment.(counter origin side)

A : Dial gauge

**NOTE**


- Specified value :  $\pm 0.05\text{mm}$



- 4 Adjust Y-rail horizontal.(measuring point on counter origin side)
- If value is outside specified value, add dial gauge value in [Adj. Tilt:\*.\*\*mm].
  - Press "Enter" key.

- 5 Repeat steps 3~4.(measuring point on counter origin side)
- [PG OK? No]
  - Select "No".
  - > [Adj. Tilt:\*.\*\*mm]
  - After confirming that the scale is within specified value, proceed to step 6.

- 6 Move jig.(measuring point on origin side)
- A : Jig  
B : Measuring point  
C : Table




- 7 Check scale.(measuring point on origin side)
- Check that scale is within specified value.
  - If value is out of specified value, perform Y-rail horizontal adjustment.(origin side)

A : Dial gauge

**NOTE**

- Specified value :  $\pm 0.05\text{mm}$



- 8 Adjust Y-rail horizontal.(measuring point on counter origin side)
- If value is outside specified value, add dial gauge value in [Adj. Height:\*.\*\*mm].
  - Press "Enter" key.

- 9 Repeat steps 7~8.(measuring point on origin side)
- [PG OK? No]
  - Select "No".
  - > [Adj. Height:\*.\*\*mm]
  - After confirming that the scale is within specified value, proceed to step 10.

- 10 Repeat steps 2~9.
- [PG OK? No]
  - Select "No".
  - > [Adj. Tilt:\*.\*\*mm]/[Adj. Height:\*.\*\*mm]
  - After confirming that the scale is within specified value, proceed to step 11.

- 11 Remove jig.


- 12 Exit adjustment menu.
- [Adj. Height:\*.\*\*mm]
  - >[Wait for a while]
  - Gantry automatically moves to origin position.
  - [PG OK? No/Yes]
  - Select "Yes".
  - [Wait for a while]
  - > [PG1:Adjust Height]

**TIP**

index=> [TOC](#)

6. Laser sensor adjustment

A : Laser sensor (left side)  
 B : Laser sensor (right side)



● Tools, Jigs, and Maintenance Part(s)

Part(s) No.	Name	Reference
DH-41690	Laser Sensor Adjustment Jig	
Generic item	Phillips screwdriver No.2	
Generic item	Hex wrench (2.5mm)	
Generic item	Flat head screwdriver	- Tip thickness: less than 1mm - Outer diameter : less than 6mm

**WARNING**


- This system (including the housing and safety device) is a Class 1 laser product. Use of controls or adjustments or performance of procedures other than those specified herein may result in radiation exposure.

**CAUTION**

- Precautions when using the laser sensor
  - Do not look into the laser beam.
  - Do not look into the laser beam with optical instruments. Doing so may cause eye damage.

**NOTE**


DH-41690  
 Laser Sensor Adjustment Jig  
 (A) Block gauge (1.5mm)  
 (B) Block gauge (2mm)  
 (C) Block gauge (19mm)




**NOTE**

- When adjusting laser sensor, use two block gauges at a time.

- Block gauge (20.5mm) required:  
 Block gauge (19mm) and block gauge (1.5mm) are used.  
 A : Block gauge(19mm)  
 B : Block gauge(1.5mm)



- Block gauge (21mm) required:  
 Block gauge (19mm) and block gauge (2mm) are used.  
 A : Block gauge(19mm)  
 C : Block gauge(2mm)




**NOTE**

- The outline of this adjustment is described below.
  - 1 Select adjustment menu.
  - Gantry automatically moves to adjustment position.
  - 2 Place block gauge on table.
  - 3 Check mounting position on laser sensor.

When using block gauge  
(20.5mm):  
-> Laser beam passes through.

\* Laser sensor (left side):  
LED (green) : light on  
LED (red) : Light off


A : Laser sensor (right side)  
B : Laser sensor (left side)  
C : Block gauge (20.5mm)



When using block gauge  
(21mm) :

-> Laser beam is blocked..  
\* Laser sensor (left side) :  
LED (green) : light on  
LED (red) : Light on


A : Laser sensor (right side)  
B : Laser sensor (left side)  
D : Block gauge (21mm)



**NOTE**

- Adjustment of right side laser sensor mounting position (front-rear)  
Adjustment procedure is explained below.

A : Laser sensor cover R  
B : Hex socket screw with split washer\_M3x6 (x2)  
C : Adjustment knob  
D : Laser sensor(right side)  
E : Laser sensor(left side)



To move laser sensor to front side:

- 1 Loosen screws about half way. (x2)
- 2 Turn adjustment knob to the right side.
- 3 Tighten screws. (x2)


To move laser sensor to rear side:

- 1 Loosen screws about half way. (x2)
- 2 Turn adjustment knob to the left side.
- 3 Tighten screws. (x2)

**NOTE**

- Adjustment of right side laser sensor mounting position (slant)  
Adjustment procedure is explained below.

- A : Laser sensor cover R
- B : Hex socket screw with split washer\_M3x6 (x2)
- C : Adjustment knob
- D : Laser sensor(right side)
- E : Laser sensor(left side)




- To tilt laser sensor upward:
- 1 Loosen screws about half way. (x2)
- 2 Turn adjustment knob to the right side.
- 3 Tighten screws. (x2)

- To tilt laser sensor downward:
- 1 Loosen screws about half way. (x2)
- 2 Turn adjustment knob to the left side.
- 3 Tighten screws. (x2)

**NOTE**

- Adjustment of right side laser sensor mounting position (up-down)  
Adjustment procedure is explained below.

- A : Laser sensor cover R
- B : Hex socket screw with split washer\_M3x6 (x2)
- C : Adjustment knob
- D : Laser sensor(right side)
- E : Laser sensor(left side)





- To move laser sensor to lower side:
- 1 Loosen screws about 1 way. (x2)
- 2 Turn adjustment knob to the right side.
- 3 Tighten screws. (x2)

- To move laser sensor to upper side:
- 1 Loosen screws about 1 way. (x2)
- 2 Turn adjustment knob to the left side.
- 3 Tighten screws. (x2)

**NOTE**


- Adjustment of left side laser sensor mounting position (up/down)  
Adjustment procedure is explained below.

A : Laser sensor cover L  
 B : Hex socket screw with split washer\_M3x6 (x2)  
 C : Adjustment knob  
 D : Laser sensor(left side)




To move laser sensor to lower side:

- 1 Loosen screws about 1 way.(x2)
- 2 Turn adjustment knob to the right side.
- 3 Tighten screws. (x2)



To move laser sensor to upper side:

- 1 Loosen screws about 1 way.(x2)
- 2 Turn adjustment knob to the left side.
- 3 Tighten screws. (x2)

**TIP**

index=> [TOC](#)

## 6.1. Laser sensor adjustment(check)

**NOTE**

- It can be checked without removing laser sensor cover.  
LED of laser sensor is checked through gap in laser sensor cover.

## ● Procedure

- 1 Select check menu.  
- [Check1:Adj.Mecha] -> [Mecha3:Adj. Laser] -> [Start Adj.->Enter]
- 2 Move gantry.  
- [Start Adj.->Enter] -> [Wait for a while] -> [Adjust End->Enter]
- 3 Check mounting position of laser sensor. (left side/blockade)
- 4 Check mounting position of laser sensor. (left side/pass through)
- 5 Check mounting position of laser sensor. (right side/blockade)
- 6 Check mounting position of laser sensor. (right side/pass through)
- 7 Check mounting position of laser sensor. (firmware)  
- [Adjust End->Enter] -> [Remove JIG->Enter] -> [Confirming]
- 8 Display sensor position.  
- [Sensor Pos:\*.\*\*mm]
- 9 Exit check menu.  
- [Sensor Pos:\*.\*\*mm]->[Wait for a while]->[Mecha3:Adj. Laser]

## ● Procedure(details)

- 1 Select check menu.  
- Starts self-diagnosis function mode.  
- Select check menu.  
- [Check1:Adj.Mecha]  
-> [Mecha3:Adj. Laser]  
-> [Start Adj.->Enter]

- 2 Move gantry.
- [Start Adj.->Enter]
  - Press "Enter" key.
  - [Wait for a while]
    - Gantry automatically moves to adjustment position.
  - [Adjust End->Enter]

- 3 Check mounting position of laser sensor. (left side/blockade)
- Place block gauge(21mm) on left side of table.
  - Check that laser beam is blocked.
  - If laser beam passes through, perform laser sensor adjustment.


=>6.2. Laser sensor adjustment(adjustment)

A : Block gauge(21mm)

B : Laser sensor(left side)

#### NOTE

- When using block gauge(21mm) :
  - > Laser beam is blocked.
- \* Laser sensor (left side) :
  - LED (green) : light on / LED (red) : Light on



- 4 Check mounting position of laser sensor. (left side/pass through)
- Place block gauge(20.5mm) on left side of table.
  - Check that laser beam passes through.
  - If laser beam is blocked, perform laser sensor adjustment.


=>6.2. Laser sensor adjustment(adjustment)

A : Block gauge(20.5mm)

B : Laser sensor(left side)

#### NOTE

- When using block gauge(20.5mm) :
  - > Laser beam passes through.
- \* Laser sensor (left side) :
  - LED (green) : light on / LED (red) : Light off




- 5 Check mounting position of laser sensor. (right side/ blockade)
- Place block gauge(21mm) on left side of table.
  - Check that laser beam is blocked.
  - If laser beam passes through, perform laser sensor adjustment.

=>6.2. Laser sensor adjustment(adjustment)

A : Block gauge(21mm)  
 B : Laser sensor(right side)  
 C : Laser sensor(left side)

#### NOTE

- When using block gauge(21mm) :  
-> Laser beam is blocked.
- \* Laser sensor (left side) :  
LED (green) : light on / LED (red) : Light on




- 6 Check mounting position of laser sensor. (right side/ pass through)
- Place block gauge(20.5mm) on left side of table.
  - Check that laser beam passes through.
  - If laser beam is blocked, perform laser sensor adjustment.

=>6.2. Laser sensor adjustment(adjustment)

A : Block gauge(20.5mm)  
 B : Laser sensor(right side)  
 C : Laser sensor(left side)

#### NOTE

- When using block gauge(20.5mm) :  
-> Laser beam passes through.
- \* Laser sensor (left side) :  
LED (green) : light on / LED (red) : Light off



- 7 Check mounting position of laser sensor. (firmware)
- [Adjust End->Enter]
  - Press "Enter" key.
  - [Remove JIG->Enter]
  - Press "Enter" key.
  - [Confirming]
    - Firmware checks the mounting position of the laser sensor.
  - If [Adjust Fail] is displayed, perform laser sensor adjustment.
- =>6.2. Laser sensor adjustment(adjustment)

- 8 Display sensor position.
- [Sensor Pos:\*.\*\*mm]
  - If value is out of specified value, perform laser sensor adjustment.
- =>6.2. Laser sensor adjustment(adjustment)

**NOTE**

- Specified value : 0.5mm~1.0mm

- 9 Exit check menu.
- [Sensor Pos:\*.\*\*mm]
  - Press "Enter" key.
  - [Wait for a while]
  - > [Mecha3:Adj. Laser]

**TIP**

index=> [TOC](#)

## 6.2. Laser sensor adjustment(adjustment)

## ● Procedure

- 1 Select check menu.
  - [Check1:Adj.Mecha] -> [Mecha3:Adj. Laser] -> [Start Adj.->Enter]
- 2 Move gantry.
  - [Start Adj.->Enter] -> [Wait for a while] -> [Adjust End->Enter]
- 3 Open front cover.
- 4 Adjust mounting position of laser sensor. (right side/front-rear)
- 5 Adjust mounting position of laser sensor. (right side/slant)
- 6 Adjust mounting position of laser sensor. (left side/blockade)
- 7 Adjust mounting position of laser sensor. (left side/pass through)
- 8 Adjust mounting position of laser sensor. (right side/blockade)
- 9 Adjust mounting position of laser sensor. (right side/pass through)
- 10 Check mounting position of laser sensor.
- 11 Check mounting position of laser sensor. (firmware)
  - [Adjust End->Enter] -> [Remove JIG->Enter] -> [Confirming]
- 12 Display sensor position.
  - [Sensor Pos:\*.\*\*mm]
- 13 Exit check menu.
  - [Sensor Pos:\*.\*\*mm]->[Wait for a while]->[Mecha3:Adj. Laser]

## ● Procedure(details)

- 1 Select check menu.
  - Starts self-diagnosis function mode.
  - Select check menu.
    - [Check1:Adj.Mecha]
    - > [Mecha3:Adj. Laser]
    - > [Start Adj.->Enter]


- 2 Move gantry.
- [Start Adj.->Enter]
  - Press "Enter" key.
  - [Wait for a while]
    - Gantry automatically moves to adjustment position.
  - [Adjust End->Enter]

- 3 Open front cover.
- NOTE**
- => Operation manual

- 4 Adjust mounting position of laser sensor. (right side/ front-rear)
- Adjust front-rear position of laser sensor(right side).
  - Adjust laser so that it hits vertical position of hole in laser sensor(left side).

A : Laser  
 B : Hole in laser sensor(left side)  
 C : Laser sensor(left side)  
 D : Laser sensor(right side)


- NOTE**
- Adjustment procedure
    - Adjustment of right side laser sensor mounting position (front-rear)



- 5 Adjust mounting position of laser sensor. (slant)
- Adjust slant position of laser sensor(right side).
  - Adjust laser so that it hits hole in laser sensor(left side).

A : Laser  
 B : Hole in laser sensor(left side)  
 C : Laser sensor(left side)  
 D : Laser sensor(right side)

- NOTE**
- Adjustment procedure
    - Adjustment of right side laser sensor mounting position (slant)



- 6 Adjust mounting position of laser sensor. (left side/ blockade)
- Place block gauge(21mm) on left side of table.
  - Adjust up-down position of left side laser sensor.
  - Adjust laser so that it shuts off block gauge (21mm).

A : Jig 2

B : Block gauge(21mm)


C : Laser sensor(left side)

#### NOTE

- Adjustment procedure
  - Adjustment of left side laser sensor mounting position (up-down)

#### NOTE

- When using block gauge(21mm) :
  - > Laser beam is blocked.
- \* Laser sensor (left side) :
  - LED (green) : light on / LED (red) : Light on



- 7 Adjust mounting position of laser sensor. (left side/pass through)
- Place block gauge (20.5 mm) on left side of table.
  - Adjust up-down position of left side laser sensor.
  - Adjust laser so that it passes through block gauge (20.5 mm).

A : Jig 2

B : Block gauge(20.5mm)


C : Laser sensor(left side)

#### NOTE

- Adjustment procedure
  - Adjustment of left side laser sensor mounting position (up-down)

#### NOTE

- When using block gauge(20.5mm) :
  - > Laser beam passes through.
- \* Laser sensor (left side) :
  - LED (green) : light on / LED (red) : Light off



- 8 Adjust mounting position of laser sensor. (right side/ blockade)
- Place block gauge(21mm) on right side of table.
  - Adjust up-down position of right side laser sensor.
  - Adjust laser so that it shuts off block gauge (21 mm).

A : Jig 2

B : Block gauge(21mm)

C : Laser sensor(right side)

D : Laser sensor(left side)

**NOTE**


- Adjustment procedure
  - Adjustment of right side laser sensor mounting position (up-down)

**NOTE**

- If laser cannot be blocked by adjusting right side laser sensor mounting position (up-down), also adjust right side laser sensor mounting position (slant).

**NOTE**

- When using block gauge(21mm) :
  - > Laser beam is blocked.
  - \* Laser sensor (left side) :
    - LED (green) : light on / LED (red) : Light on



- 9 Adjust mounting position of laser sensor. (right side/ pass through)
- Place block gauge(20.5mm) on right side of table.
  - Adjust slant and up-down position of right side laser sensor.
  - Adjust laser so that it passes through block gauge(20.5mm).

A : Jig 2

B : block gauge(20.5mm)

C : Laser sensor(right side)

D : Laser sensor(left side)

**NOTE**


- Adjustment procedure
  - Adjustment of right side laser sensor mounting position (up-down)

**NOTE**

- If laser cannot pass through by adjusting right side laser sensor mounting position (up-down), also adjust right side laser sensor mounting position (slant).

**NOTE**

- When using block gauge(20.5mm) :
  - > Laser beam passes through.
  - \* Laser sensor (left side) :
    - LED (green) : light on / LED (red) : Light off



- 10 Check mounting position of laser sensor  
=>6.1. Laser sensor adjustment(check)  
- If value is out of specified value, perform laser sensor adjustment.  
>Refer to step.3~9.

**NOTE**

- Specified value :
  - When using block gauge(21mm) :
    - > Laser beam is blocked.
    - \* Laser sensor (left side) :  
LED (green) : light on / LED (red) : Light on
  - When using block gauge(20.5mm) :
    - > Laser beam passes thorough.
    - \* Laser sensor (left side) :  
LED (green) : light on / LED (red) : Light off

- 11 Check mounting position of laser sensor. (firmware)  
- [Adjust End->Enter]  
- Press "Enter" key.  
- [Remove JIG->Enter]  
- Press "Enter" key.  
- [Confirming]
  - Firmware checks the mounting position of the laser sensor.  
- If [Adjust Fail] is displayed, perform laser sensor adjustment.  
=>Refer to step.3~9.

- 12 Display sensor position.  
- [Sensor Pos:\*.\*\*mm]  
- If value is out of specified value, perform laser sensor adjustment.  
>Refer to step.3~9.

**NOTE**

- Specified value : 0.5mm~1.0mm


- 13 Exit check menu.  
- [Sensor Pos:\*.\*\*mm]  
- Press "Enter" key.  
- [Wait for a while]  
-> [Mecha3:Adj. Laser]

**TIP**

index=> [TOC](#)

7. Check gantry operation

A : Gantry



TIP

index=> [TOC](#)


● Tools, Jigs, and Maintenance Part(s)

Part(s) No.	Name	Reference
DH-41690	Laser Sensor Adjustment Jig	
Generic item	Phillips screwdriver No.2	
Generic item	Hex wrench (2.5mm)	
Generic item	Flat head screwdriver	- Tip thickness: less than 1mm - Outer diameter : less than 6mm

NOTE

DH-41690  
Laser Sensor Adjustment Jig

- Ⓐ Block gauge (1.5mm)
- Ⓑ Block gauge (2mm)
- Ⓒ Block gauge (19mm)



## 7.1. Check gantry operation(check)

## ● Procedure



- 1 Select check menu.
  - [Check18:Gantry Move]
- 2 Remove media.
  - [Media Remove->Enter] -> [Wait for a while]
- 3 Check gantry operation.(Front/High)
  - [Pos.3:Front/High] -> [Moving]
- 4 Check gantry operation.(Rear/Low)
  - [Pos.1:Rear/Low] -> [Moving]
- 5 Exit check menu.
  - [Pos.1:Rear/Low] -> [Wait for a while] -> [Check18:Gantry Move]



## ● Procedure(details)

- |   |  |
|---|--|
| 1 | Select check menu. <ul style="list-style-type: none"> <li>- Starts self-diagnosis function mode.</li> <li>- Select check menu<br/>[Check18:Gantry Move]</li> </ul>   |
| 2 | Remove media. <ul style="list-style-type: none"> <li>- [Media Remove-&gt;Enter]</li> <li>- Press "Enter" key.</li> <li>- [Wait for a while]</li> <li>- Gantry automatically moves to origin position.</li> </ul> |

**NOTE**

- Origin position(PF) : rear side[Rear]
- Origin position(PG) : lower side[Low]

- |   |  |   |
|---|--|---|
| 3 | heck gantry operation.(Front/High) <ul style="list-style-type: none"> <li>- Select [Pos.3:Front/High].</li> <li>- Press "Enter" key.</li> <li>- [Moving]             <ul style="list-style-type: none"> <li>- Gantry automatically moves to front/upper side.</li> </ul> </li> <li>- Check that gantry does not stop operating.</li> <li>- If gantry stop operating, perform laser sensor adjustment.</li> </ul> <p>=&gt;7.2. Check gantry operation(adjustment)</p> <p>A : Gantry</p> |   |
|---|--|---|

- |   |  |  |
|---|--|--|
| 4 | Check gantry operation.(Rear/Low) <ul style="list-style-type: none"> <li>- Select [Pos.1:Rear/Low].</li> <li>- Press "Enter" key.</li> <li>- [Moving]             <ul style="list-style-type: none"> <li>- Gantry automatically moves to rear/lower side.</li> </ul> </li> <li>- Check that gantry does not stop operating.</li> <li>- If gantry stop operating, perform laser sensor adjustment.</li> </ul> <p>=&gt;7.2. Check gantry operation(adjustment)</p> <p>A : Gantry</p> |   |
|---|--|--|

- |   |   |
|---|---|
| 5 | Exit check menu. <ul style="list-style-type: none"> <li>- [Pos.1:Rear/Low]</li> <li>- Press "Cancel" key.</li> <li>- [Wait for a while]             <ul style="list-style-type: none"> <li>- Gantry automatically moves to origin position.</li> </ul> </li> <li>- [Check18:Gantry Move]</li> </ul> |
|---|---|

**TIP**

index=&gt; TOC

## 7.2. Check gantry operation(adjustment)

**NOTE**

- Gantry operation check (adjustment) is continued at location where gantry operation has stopped.

## ● Procedure

- 1 Adjust mounting position of laser sensor. (right side/slant)
  - [Media Remove->Enter]
- 2 Check gantry operation.

## ● Procedure(details)

- 1 Adjust mounting position of laser sensor. (right side/slant)
  - Adjust slant position of laser sensor(right side).
  - Adjust laser so that it hits hole in laser sensor(left side).

A : Laser


B : Hole in laser sensor(left side)

C : Laser sensor(left side)

D : Laser sensor(right side)

**NOTE**

- Adjustment procedure
  - Adjustment of right side laser sensor mounting position (slant)
- =>6. Laser sensor adjustment



- 2 Check gantry operation.
  - =>7.1. Check gantry operation(check)
  - Check that gantry does not stop operating.
  - If gantry stop operating, perform laser sensor adjustment.
  - =>Refer to step.1.

TIP

index=> TOC

Appendix.1. Self-diagnosis

Self-diagnostic mode menu used in this manual is described below.

**NOTE**


- Applicable Firmware : Ver.1.01 or later.(No.SS620B)

**TIP**

index=> [TOC](#)

Appendix.1.1. PG height adjustment

● Operation panel




**TIP**

index=> [TOC](#)

Appendix.1.2. Laser sensor adjustment

● Operation panel



\*1 When the display goes back to the Adjust PG Menu , the gantry stays in the current position.


\*2 The message is displayed in two lines.

**TIP**

index=> [TOC](#)

Appendix.1.3. UV-LED mounting position adjustment

● Operation panel




\*1 When the display goes back to the Mechanical Adjustment Menu , the gantry stays in the current position.

**TIP**

index=> [TOC](#)

## Appendix.1.4. Gantry move

## ● Operation panel

**TIP**index=> [TOC](#)